

### PKD Battery install:

For your PKD sound board, you must install the batteries with the correct polarity. The red wire with the battery spring is positive (+), and the brown wire is negative (-). When you install the batteries, make sure you hook them up abiding this polarity. The positive side of the 357 battery (flat side) goes to the red wire, and the negative side goes to the brown wire.

To hook up 4 batteries, simply stack them positive to negative and use some electrical or other tape to secure them together.

Here is a simple hookup diagram:

